

Seicane S167017 2007-2010 Ford Mondeo S max aftermarket car radio upgrade installation replacement instruction

Seicane S167017 2007-2010 Ford Mondeo S-max car radio after installation



Please note:

This unit can be suitable for the following cars which are also with the same installation steps as follows.

- 2007-2010 Ford Mondeo
- 2010 Ford Tourneo Connect
- 2010 Ford Transit Connect
- 2008-2010 Ford S-max

Precautions for this installation:

1. Before you start up any work, park your car well and unplug the negative power cable to avoid any danger.
2. Please make sure that all fastened wires are isolated with electrical tape.
3. Please make sure the ignition is off to avoid short circuit.
4. Please prepare a lever and a screwdriver before the removal and the installation.
5. For your convenience, here's the recommended tools for removal and installation from Seicane, please check for more details: <http://www.seicane.com/car-dvd-dismantling-device-srd-400>

2007-2010 Ford Mondeo S-max car radio installation guide

1. Remove the panel with a lever.



2. Unscrew four screws holding the original radio with a screwdriver.



3. Gently take the original car radio out of the dashboard.



4. Disconnect all connectors at the back of the original car radio.

5. Check all the accessories for the new Seicane car radio.



6. Connect the harnesses to the back of the new Seicane car radio.



7. Connect the Seicane car radio to your original car radio 's plugs.

8. Turn on the new Seicane radio to have a careful check if everything works well. If it doesn't, please check whether all the cables are connected correctly.

9. Put the new Seicane radio into the dash.

10. Put everything into their original place.