

This manual without any kind of warranty, the position of expression or other implied. If any because of the use of all of the information of the manual, or they use the products mentioned, caused by direct or indirect loss of data, loss of profits, or the cause of termination of the company, our company and our employees definitely do not assume any responsibility. In addition, the specifications of the products mentioned in this manual for information purposes only, may be modified according to the product specific to prevail in kind, the content will be updated at any time absolutely without prior notice.

Product and company names talked about in this manual are only for identification purposes, these names may be registered trademarks and copyrights of other companies.



### **TIPS**

For your safety, while driving please do not watch video or operating this machine. Set the volume to clearly hear outside sound levels while driving. Before you begin, carefully read this manual and other manuals and understand this manual and machine safety tips and warning signs, after reading it, please put it on the readily accessible place for ready reference.

- 1. First pay attention to traffic safety.
- 2. If when you encounter difficulties in operating the system, park your car in a safe place before the operation.
- 3. Please do not let children operate this machine, so as not to cause personal injury or damage to the machine.
- 4. When using satellite navigation feature, please follow the rules of the road driving.
- 5.Please do not use this machinery in place to prohibit the use of electronic equipment or open flame is prohibited, such as gas stations, wineries, electromagnetic strong interference region, or it may be dangerous.
- 6.Do not self–service, maintenance, or install the machine. In case of the power is on, do not install or repair the machine. It is very dangerous if the person who did not receive the electronic equipment or vehicle installation training or lack of experienced personnel to install and repair the machine.
- 7.Do not store or install the machine in direct sunlight place, nor to be placed in the environment of other harmful substances, especially LCD screen, when installing, if the LCD screen just in the air conditioner near the ventilation duct, to ensure that cold do not wind or hot air blowing directly on the machine, otherwise it may damage the machine, even for personal injury. the display, otherwise it will cause damage to the display or the touch screen.shock, do not expose it in the moist air, also do not to let the liquid spilled on the machine.
- 8.Do not use sharp objects to scratch or paint on the display, do not take a hard object vigorously push on 9.In order to ensure the normal operation of the machine and to prevent the occurrence of fire or electric

#### **Tips and Warnings**

To emphasize some important information in the user manual,  $\Lambda$  particular attention to this lable, it means some important Warning and Tips imformation.

### **Safety caution**

Please read through the manual before you install this machine. You're suggested to ask the professional car audio engineers to install this machine.



This product fits for 12V car power system(must be connected with the ground wire). Please do not install this product to the car with 24V power system. Or the machine will be damaged.



Please do not change the power fuse by yourself without any guide of the professional people. Use the unsuitable fuse, will lead to the damage of the machine or cause fire alarm.



To avoid violating the traffic rules, the drivers are not allowed to watch programs or operate this machine when driving, in order to avoid unnecessary traffic accident.



For safety and ensure the normal use of this product, please askthe professional people to install this product, and do not disassemble or maintain this product, to avoid the damage of this product and some accidents, details please refer to your local car audio shops.



Please do no put this product in damp environment and water, to avoid the electric shock caused by short circuit, or other unnecessary losses and fire alarm.

Attention: To avoid short circuit, please note to turn off the car and disconnect the connection of cable ACC with B+ before install the machine.

#### PRODUCT'S RESET

- 1. Please reset the unit before useing it for first time or after changeing the battery.
- 2. Please reset the unit if cannot use it propertly
- 3. The unit will be reseted and turn off, back to the factory state if press the RESET button by sharp object or click system reset. the previous date before reset will be retained.

Warning: Press RESET or system initialization will back to the factory settings.

### **CATALOGUE**

1. Main interface 1	12、UNIT SETTING······15
2、 Main Menu interface·····3	13、GPS Map17
3、DVD Player·····4	14、3G······18
4、Radior5	15、AirPin (iphone) connection·····19
5、Digital TV······6	16、Android interconnected······21
6、.Bluetooth7	17、OBD connection·····24
7、Video player·····10	18、APK the third-party software installation · 27
8、Music player·····11	19、System parameters····29
9、Photo storage·····12	20、Frequently question troubleshooting····30
10、AVIN13	21、Care and Maintenance·····31
11、File Managemen·····14	

# **Function Operation**

#### 1. Main interface

Every times the system booting, first enter the main interface, all the interface can slide from left to right. It can switch to main menu in any states through clicking the upper left corner ICONS . The left side of the main interface widgets can vary from bluetooth, music and other applications






There will be a notice bar on the interface when you dragging from up to down



Click the icon in the upper left corne to remove the background of the program,, click on the top left corner icon to enter the gallery page, etc





### **Function Operation**

#### 2. Main Menu interface

This car multimedia system provides a DVD, radio, mobile digital TVS, driving records, Internet, bluetooth, movies, music, navigation, external audio and video, and other functions. Click on the main interface to the left icon to enter the main menu interface. Through the point of each function module icon, to enter the use of related functions. In any other state, according to the main menu or click the upper right corner to return to the icon, also can return to the main menu;





#### Main functions:

- 1.DVD
- 2.AVIN
- 3.Bluetooth
- 4.Radio
- 5.Digital TV 6.Picture
- 7.Music player 8.Video player
- 9.lpod
- 10.APK Ghost
- 11.Setting
- 12.File management
- 13.Driving recorder

#### 3、DVD Player

In the main interface or other modes, the optical disk gently put into the plate mouth, is automatically into the CD machine, and will automatically be transferred to DVD player interface, shown in the following figure. When you playing the disc, the control menu will pop up if you touch anywhere in the screen.



DVD player interface

- 1, paging capabilities
- 2, 🛛 PRE
- B. Rewind
- 4. | PLAY/PAUSE
- 5、 STOP
- 6、 DD Fast Forward
- 7. DI NEXT

### **Function Operation**

#### 4. Radio

Click BAND on the panel or press the radio in the main menu to enter Radio.




Radio interface

- 1 \ Searching: At once into the automatic search radio mode, press it again to stop it.
- 2 N SRS
- 3 、 ♠ Far short-range
- 4 Nort press search move forward 0.1 M, long press forward a station.
- 5 \ Short press search move back 0.1 M, long press back a station
- 6 × AM Switch, can save 12 effective stations.
- Switch, can save 18 effective stations;

### 5、Digital TV

Click TV in main menu, it will turn into digital TV interface(as graph 1) Touch the right corner of the screen for few seconds untill touchscreen surface appears(as graph 2), click to return to main menu.





(graph 3)



(graph2)

- Nolume button, press this button to mute or adjust volume
   Press the button to increase or reduce the volume.
- 2.Press this button can view the TV menu and choose auto searching, program list and into the setting.
- 3. Previous channel
- 4.Next channel
- 5. Cancel Touch strip display
- 6.TV channels
- 7.Enter to main menu
- 8.Back to the main menu
- 9. Volume down
- 10.Volume up

### **Function Operation**

#### 6. Bluetooth


choose Bluetooth radio module or press the Bluetooth mode key to enter the Bluetooth mode on the panel, when the phone is paired with Bluetooth, all interface icons will light up and the top of the screen will appear icon.



Bluetooth dial-up interface

- This button is used to switch to a Bluetooth dial-up interface
- 2) This button is used to switch to a Bluetooth phone book interface
- This button is used to switch to a Bluetooth phone recording interface
- 4) This button is used to switch to a Bluetooth music interface:
- 5) This button is used to pair a Bluetooth device screen, tap to search for Bluetooth pairing name;
- 6)、 Bluetooth settings interface;

- 9)、 🔼 End key
- Shift key, when Bluetooth calls, switching sound between mobile and vehicles



Bluetooth phone book interface



Bluetooth pairing record interface

- 1) \ o for the phonebook quickly search the first letter of the name;
- 3) . O Download phonebook in photo;
- 1) 、 search for the phone pairing name;
- 2) connecting the searched pairingn names;
- 4) Delete the selected Bluetooth pairing records;

# **Function Operation**



Bluetooth settings interface



Bluetooth music interface

- 1). Setting the name of the machine Bluetooth device
- 2). Setting the name of the machine Bluetooth device

- 1), Bluetooth music play / pause button;
- 2). Play the last song of Bluetooth music
- 3). Play the next song of Bluetooth music;

### 7. Video player

after Click to play video modules can play audio and video file the system comes or external media card and USB /SD card inside the mouth of Multimedia files; support H.263 P3, MPEG-4 Simple Profile, H.264 / AVC ...format.



 Video interface from right to left drag playlist can be shown, from left to right drag can display the folder management interface

- 1、 Fullscreen button
- 2. the last
- 3. I play/pause
- 4、 stop
- 5. Di the next
- 6. the list of video files;



### **Function Operation**

### 8. Music player


After Click to play audio modules can play audio and video file the system comes or external media card and USB /SD card inside the mouth of Multimedia files; support: WMA MP3 and other audio formats...



Music player interface

 music / video interface can be displayed from right to left and drag the playlist, drag from left to right to display the folder management

- 1)、摇滚 Sound mode switch
- 2), I the last
- 3), II play/pause
- 5), l= the list of music files;
- 6), 2 Switch lyrics and spectrum;
- 7), Song Play Mode



#### 9. Photo storage

Click photo /It will display the photo from Photo store /Photo list paly mode ,The photoes are all from RAM/SD/USB. In the photo store, You can not only loading the photos in the storage but also can play the video file from SD/USB ,as below shows:





# **Function Operation**

#### 10, AVIN

Click Icon AVIN, it will play audio and video from external device with sounds come out at the same time. As photo shows:





### 11. File Management

In File management you can copy the files from local memory to host memory (as photo shows)






- 1) storage :storage files from host memory
- 2) Copy:Tick the files which you need and then click copy
- 3) . Paste: Paste the files to the place where you want it to be
- 4) Delete: Cofirm the files need to delete and click delte

### **Function Operation**


#### 12. UNIT SETTING

Click setting in Main munue, turn into setting screen for wifi, audio, app, gps setting, driving setting, language input, date, time etc, we will just describe some of the regular functions

1.GPS, When GPS and music give the sound at the same time, the mode is adjustable between the background audio volum and gps mixing audio .




2. Driving setting ,Braking is able to start a mode,switch on/off the warning ,when vedio play on.



# **Function Operation**

#### 13、GPS Map

Firstly, installing the GPS in the APK manager, After finish installment, please take more for reference from the GPS operation instruction.



#### 14、3G

3G: insert the USB 3G devices, automatically after about 30 seconds in the 3G icon appears at the top of the tip, can use 3G Internet access



### **Function Operation**

### 15. AirPin (iphone) connection

In the main screen click AirPin (PRO) icon, click the icon in the following Internet interface; Apple mobile phone to open car machine WIFI after personal hotspot connection iphone personal hotspot, restarted the car machine for ITV @ 3 start automatically, and then hold down the apple on the bottom of the screen to launch the menu bar select AirPlay, then check the ITV @ 3 and open mirror finish apple mobile interconnection.









8



16. Android interconnected

**Function Operation** 

At home screen click on icon, click the icon in the following Internet interface, after open android debug mode, connecting with cable car USB port, and then open the icon automatic connection and completes the image transmission, when after the success of the bluetooth connection, realizes the image and voice synchronous transmission.






2



3



# **Function Operation**





6

\_\_\_

#### 17, OBD connection

find the icon in main menu to enter the OEM, find torque.apk file and install it, after installing then enter to search OBD Bluetooth name and connect it, and then click on the icon on the main nemu to enter the OBD, after setting OBD2 adaper setting, the connection type and the Bluetooth device address, connect successfully.








3




### **Function Operation**





6





# **Function Operation**

#### 18. APK the third-party software installation

Click on the icon 🙀 to enter the APK installer, choose "install", Find the installation package file in the storage path, and then install it follow the step tips; In the installation process, it will display a security tips as the photo below.





♥ ♥ 08:06 ₪ : ጏ CldNavi\_1406CC\_KAIYUE\_91 3











# System parameters

Specifications	FM=radio section	
Operating voltage: 12V	FM Frequency range: 87.5MHz-108.0MH	
Operating voltage range: 9V-15.5V	Signal to-noise ratio (-50db): 15dBu	
Signal to-noise ratio (-50db): 15dBu	sensitivity (-30db): 10dBu	
	Frequency response range: 30KHz 15KHz (3dB)	

#### DVD/CD

Compatible formats: DVD-R, DVD-RW, DVD+R, DVD+RW, CD-R, CD-RW, MP3, WMA, HDCD, SVCD, MPEG, JPEG

Audio signal to noise ratio: 85dBA	Dynamic range : 95bB	Dynamic range : 20Hz-20KHz ( 3dB )
Digital Audio Sampling: 24bit	Electronic Stability Program ( ESP )	DVD 2-3s CD-DA 10s Mp3 100s WMA 200s Mechanical Stability Program: 10 200KHz , X/Y/Z: 1, 0G Power output: 50W*4 Input Impedance: 4 Ohm SNR: 70dBA

Video section	display section	Ambient temperature:
Format: NTSC, PAL (automatic identification)	Screen size : 7 inches	Operating temperature: -20°C + 60°C
Output: 1VP-P (75 Ohm)	Screen Type : TFT	Storage temperature:-30°C +70°C
Input: 1VP-P (75 Ohm)	Screen resolution : 1024*600	Working humidity: 45% -80%
		Storage humidity: 30-90%

### Frequently question troubleshooting

1. Quest i on: Failure to open the unit

Reason: Haven't installed the canbus properly Solution: Configure the canbus properly

2. Question: Failure to enter the GPS navigation Reason: Not setting the gps navigation path correctly Solution: Reset the gps navigation route

3. Question: No BT function Reason: No phone connection

Solution: Enter the BT set up and check the machine name and code

4. Question: Failure of touch screen Reason: Touch screen deflected Sol ution: Recalibrate the touch screen



5. Question: Failure of specific speaker Reason: Incorrect audio set up Solution: Set audio corretly

6. Quest i on: Failure of navigation's signal Reason: Not connect GPS antenna or not connect the GPS antenna correctly Sol ut i on: Connect the GPS antenna properly

7. Question: Failure of play CD fluency Reason: the broken CD Sol ut i on: clean or replace the CD

8 . Question: when paly the VCD, the replay and search functions missing Reason: PBC function loop

9,Question:GPS unable to locate Reason: no GPS signal,or the GPS antenna plug—in trouble Solution:move the location,or replace the GPS antenna,or plug—in again

10, Question:can't play the CD Reason : forgot put into the CD inside Solution : put into the CD

Solution: stop the PBC function

### **Care and Maintenance**

The car entertainment & navigation systems need to be operated carefully, considering its excellent designand technology. The following suggestions will help you to fulfill the obligation of warranty terms and conditions.

- 1. Keep all the parts, accessories of the car entertainment & navigation systems away from the children.
- 2. Please keep dry. The rainwater, moisture and other kinds of liquid may contain mineral substance, which will corrode the electronic circuits. The soaking or moisture will ruin the components, cause irreparable damage.
- 3.Do not use or put the headunits in the dusty or smudgy place, which may damage its detachable elements.
- 4. Keep the headunits away from the extremely hot place. The high temperature will shorten the acceptable life, damage the battery, deform or melt the plastic parts.
- 5. Keep the headunits away from the extremely cold place. Otherwise the temperature increment may accumulate moistureinside, which will damage the circuit board.
- 6.Please do not throw, knock or shock the machine with great force, otherwise it may be ruined.
- 7.Do not attempt to destructuralize the machine, this will damage it, especially to the non-professionals.
- 8.Do not use the strong chemicals, detergent or strong abluent to wash the machine.
- 9.keep away the electromagnetic, radioactive or magnetic equipment when use the machine or store it.
- 10. When wipe the screen, use the soft and clean cloth, ordinary paper is not recommended.
- 11. The LCD screen is scraped easily, please use the touch pen when operate. To avoid the damage on the screen, other sharp objects are not recommended.