

Bluetooth OBDII

Use Instructions


Bluetooth OBDII for Android

1. Install OBDII




2. Install Android Software **Torque**

a) Copy software to phone from CD




b) Install Software




3. Connection OBDII


a) Search OBDII Bluetooth



b) Enter the password "1234"





c) Connection Success





4. Run Software



Click **Menu** button setting Bluetooth connection



a) Choose Connection type is **Bluetooth**



b) Choose Bluetooth Device is **OBDII**



Exit Torque, and re-run the software. Successful connection

